

Polaris

Remote Control



Use **SETUP** for all programming sequences.

Press **REC** twice to activate recording.

MENU displays your DTV screen menu.

Use **SELECT/OK** as **ENTER** for ordering PPV events, and to tune programs from the program guide.

GUIDE displays the program guide and other tabs with channel groupings (Subscribed, All, Favorites, HD and PPV).

LAST recalls the last channel, to page back one screen in the main menu, or to delete an entry.

VOL+/- raises (or lowers) the sound volume.

DAY +/- moves a day forward (or back) on your DTV program guide.

Use the keypad (**0 - 9**) to directly select channels (e.g. 09 or 31).

To turn on your television or set-top box, press **TV** or **CBL** once.

INFO displays current channel and program information.

ARROW keys move the cursor in the program guide and menu screens.

Use **EXIT** to exit out of any menu or guide display.

Use **CH+/-** to select the next higher (or lower) channel.

MUTE turns sound off or on.

PAGE +/- moves up (or down) through menu screens and the program guide.

To Troubleshoot

- 1 Press CBL button.
- 2 Power cycle the set-top box.
- 3 Make sure there are no obstructions between the remote and set-top box.
- 4 Replace the remote's batteries.
- 5 Replace the remote.

Code for TV 1:

--	--	--	--

Code for TV 2:

--	--	--	--

Code for TV 3:

--	--	--	--

To Program

- 1 Press the button for the device you want to program (TV or CBL), then release.
- 2 Press and hold the **SETUP** button until the selected device button flashes twice, then release.
- 3 Enter the 4-digit code (provided on this sheet). You should receive 2 quick flashes and the remote should work.

Refer to the users' guide for additional codes and advanced programming instructions.